

Antenna Nut Socket Set

Four double-ended sockets remove and install eight common domestic and foreign antenna nuts.
Heat-treated alloy steel.

Smaller sockets are 7/8" hex, larger socket is 1-1/4" hex.

INSTRUCTIONS:

Select proper socket and place over antenna.

Fully engage socket teeth in nut slots.

Turn socket with wrench.

APPLICATIONS:

MAKE	MODEL	SOCKET
Acura	'87 to current	#1
Chrysler	'87 to current	#1
Chrysler	Eclipse	#2
Chrysler	Laser	#2
Ford	Continental '89-'90	#2
Ford	Lincoln Mark VII	#3
Ford	Probe '89-'90	#2
Ford	Sable '85-'90	#3
Ford	Taurus '85-'90	#3
Ford	TownCar '89-'90	#2
GM	1977 - current	#3
GM	Cavalier '88-'90	#2
GM	GMT400 pickup C & K '89-'90	#2
GM	Sunbird '88-'90	#2
Honda	Accord	#2
Honda	Odyssey	#2
Honda	Prelude	#2
Mazda	RX7 '89-'90	#2
Mazda	926 '89-'90	#2
Mazda	626	#2
Mitsubishi	Galant	#2
Mitsubishi	Sigma	#2
Nissan	Altima	#4
Nissan	200ZX	#1
Nissan	Maxima	#2 or #4
Nissan	Pathfinder	#4
Nissan	Quest	#2
Nissan	Sentra	#1
Nissan	Stanza	#2
Toyota	Camry '87-'96	#2
Toyota	Celica '90-'97	#2
Toyota	Corolla Coupe	#4
Toyota	Tacoma Truck	#4
Toyota	Truck & 4Runner '90-'95	#2



29810
Socket #1



29820
Socket #2



29830
Socket #3



29600
Socket #4

